




① Release the lock



② Release the lock (2 steps)




③ Release the lock (2 steps)




④

Fix the back seat with the knob (2 steps)



⑤

Fix the hook with the butterfly screw (3 steps)



GPC MANUAL

CHAIR FOR GUITAR PLAYER

