

SANTA ROSA, CA 95402 USA

PO BOX 4394

P (707) 525-9941 F (707) 575-7046 EMGPICKUPS.COM

INSTALLATION INFORMATION EMG MODELS: EMG-H, HA, 58, 60, 60A, 81, 85



SPECIFICATIONS:			MODEL:				
	Н	HA	58	60	60A	81	85
Logo Color*	White	Gold	Gold	Grey	Gold	Silver	Gold
Magnet Type **	С	А	A/S	С	А	C/S	А
Resonant Frequency (KHz)	4.05	3.70	1.53	2.20	1.80	1.63	1.87
Output Voltage (String)	1.00	1.00	3.00	3.00	3.00	3.00	3.10
Output Voltage (Strum)	3.00	3.00	4.50	4.50	4.50	4.50	4.50
Output Noise (60 Hz)	-101	-101	-100	-101	-100	-100	-101
Output Impedance (Kohm)	10	10	10	10	10	10	10
Current (ପ9V (Microamps)	400	400	400	400	400	400	400
Battery Life (Hours)	600	600	600	600	600	600	600
Maximum Supply (Volts DC)	27	27	27	27	27	27	27
*Note: Logo Colors are not disting	quished on EM(G Metal Works	Pickups				

**Note: Magnet Type: A (Alnico) A/S (Alnico/Steel) C (Ceramic) C/S (Ceramic/Steel)

INSTALLATION NOTES:

All EMG Pickups are compatible with each other. EMG accessories, the VLPF, EXG, SPC or RPC Controls can be added to any EMG Pickup System without requiring an extra battery. DO NOT reconnect the bridge ground wire, EMG Pickups do not require string grounding. Use the 25K Ohm controls that are included for best results. If your output jack is a long panel style you will need a stereo jack, use a SwitchCraft 152B, soldering will be required (see the bottom of page 2). Adjust the pickup level to the strings, and at a distance that works for you, experiment. Alternate wiring diagrams are available at; emgpickups.com.

INCLUDED WITH EACH PICKUP:



WARRANTY

All EMG Pickups and accessories are warranted for a period of two years. This warranty does not cover failure due to improper installation, abuse or damage. If upon examination the pickup is determined to be defective, a replacement will be made. Warranty replacement products are covered by this same warranty. This warranty covers only those pickups and accessories sold by authorized EMG Dealers. This warranty is not transferable.

Installation Instructions:

General Notes:

Every attempt has been made to make this a solderless installation.

- There are some instances where this is not possible;
- If your instrument uses the long panel output jack and you had passive pickups you will need a new stereo output jack, the Switchcraft 152B is recommended. Soldering to the new jack will be required, see diagram #4 below.
- 2) Some instruments may already have a battery holder installed and in that case soldering may be required to the battery buss, see diagram #5 below.
- 3) Instruments with two pickups may need soldering to the selection switch in some installations.

If you are installing only one pickup use the instructions on this page. If you are installing two pickups go to page 3 and begin there.

Installation (One Pickup Guitars):

 Plug the pickup cable onto the EMG Pickup header as shown in diagram #1 and route the cable to the control cavity. If the cable is too long, wind up the excess and keep it under the pickup if possible.

Master Volume control only

2) Refer to diagram #2. Plug both the Pickup cable and the output cable onto the Volume control as shown, then go to step 4.

Master Volume and Tone control

- 3) Refer to diagram #3. Plug the Pickup cable onto the Volume control as shown. Plug a connect cable from the Volume control to the Tone control. Plug the output cable onto the tone control as shown.
- 4) Connect the wires of the output cable to the output jack by pushing the connectors on as shown.
 WHITE wire to the TIP (T) contact,
 BLACK wire to the SLEEVE (S) contact
 BLACK Battery Negative wire to the RING (R) contact.
- Using the battery buss, insert the RED wire of the pickup, and the battery RED wire. Extra pins can be used for EMG Accessories.
- 6) Put the battery in insulating foam and place it securely in the control cavity.
 We suggest that you plug in the instrument and

test it before closing the control cavity.



Diagram #1

Insert the plug onto the 3 pin header of the pickup as shown above. Note the orientation arrow.



Diagram #4

Soldering to the 152B Panel Jack:

If your instrument has a long Panel Jack like the one below you will have to solder the output cable as shown. Ground (Black) to the sleeve Signal (White) to the Tip Battery Negative (Black) to the Ring



Diagram #5

Soldering to the battery buss:

If your instrument has an older EMG Pickup you can solder the pickup RED wire to the buss. Simply use some needle nose pliers, pull out the V+ header and solder the RED Wire from the pickup(s) to any of the pins and then re-insert the header into the housing.

OUTPUT CABLE



Solder the RED wire from the Battery Holder and/or pickups and re-insert the Header into the insulation cover

Installation Instructions:

Two Pickup Guitars with Selection switch:

Guitars with two pickups and a selection switch will use the EMG B245 Pickup Buss. The Pickup Buss is a convenient way to wire your guitar without soldering. There is a separate sheet attached to these instructions that describes the Pickup Buss in detail.

In all installations it's best to find a place to mount the Pickup Buss in the control cavity before starting. Then, after the cables are routed use the velcro to mount it securely.

2 Pickups / Toggle Select Switch / Master Volume and Tone

- Install the Pickups and route the Pickup cables to the control cavity. If the cables are too long, wind up the excess and keep it under the pickup.
- Mount the Volume and Tone controls into the body.
 Plug both Pickup cables onto the Pickup Buss (BLACK Shroud) as shown,
- Refer to diagram #6a
- Bridge Pickup to position 1
- Neck Pickup to position 2.
- 3) Plug a connect cable from the Pickup Buss (position 3) to the Master Volume control as shown in diagram #6b.
- 4) Plug a connect cable from the Master Volume to the Master Tone as shown.
- 5) Strip the insulation from the switch wires and Insert them into the GREEN Terminal Block and tighten the screws with a small screwdriver.
 - The Bridge pickup goes to the BR Terminal
 - The Neck pickup goes to the NK Terminal
 - The Output of the switch goes to the O Terminal
- If there is a ground wire coming from the switch, insert it into one of the black terminals on the terminal block.
- 6) Plug the output cable onto the Master Tone control and connect the output wires to the output jack by pushing the connectors on as shown.
 - WHITE wire onto the TIP (T) contact,
 - BLACK wire onto the SLEEVE (S) contact
 - BLACK Battery Negative wire onto the RING (R) contact.

****Tips and Tricks**** Start your installation by:

- 1) Determine which type output jack your instrument has. A Stereo 12B type is Included, but if you have a long panel jack a SwitchCraft 152B Long Panel Jack will be required.
- Remove the strings, remove any existing Pickups and controls (remember the order and function of each control)
- 3) Determine a good spot for the Pickup Buss and make sure the cable or wires from the selection switch will reach the Pickup Buss,
- 4) Install the EMG Volume and Tone Controls and tighten them in.5) Then install the pickups keeping any excess cable under the pickup
- rather than in the control cavity. 6) IMPORTANT: EMG Active pickups do not require a string ground wire!
- DO NOT Reconnect the string ground, it is unnecessary. 7) Plug the RED Wires of the pickups onto the V+ Supply Buss (RED Shroud)
- along with the RED of the battery clip. Extra pins on the V+ Supply Buss are for EMG Accessories.
- 8) Put the battery in insulating foam and place it securely in the control cavity.

We suggest that you plug in the instrument and test it before closing the control cavity.





2 Pickups / Toggle Select Switch / 2 Volumes and Master Tone

- Refer to Diagram #7 (Next Page)
- 1) Install the Pickups and route the Pickup cables to the control cavity.
- If the cables are too long, wind up the excess and keep it under the pickup. 2) Mount the Volume and Tone controls into the body.
- Plug both pickup cables onto the Volume controls as shown.
- Plug a connect cable from the Bridge Volume control to the Pickup Buss (Position 1) Plug a connect cable from the Neck Volume control to the Pickup Buss (Position 2)
- 3) Plug a connect cable from the Pickup Buss (position 3) to the Master Tone control as shown.
- 4) Strip the insulation from the switch wires and Insert them into the GREEN Terminal Block and tighten the screws with a small screwdriver.
 - The Bridge pickup goes to the BR Terminal
 - The Neck Pickup goes to the NK Terminal
 - The Output of the switch goes to the O Terminal
 - If there is a ground wire coming from the switch, insert it into one of the black terminals on the terminal block.

- 5) Plug the output cable onto the Tone control and connect the wires to the output jack by pushing the connectors on as shown.
 - WHITE wire onto the TIP (T) contact,
 - BLACK wire onto the SLEEVE (S) contact
- BLACK Battery Negative wire onto the RING (R) contact.
- 6) Plug the RED Wires of the pickups onto the V+ Supply Buss (RED Shroud) along with the RED of the battery clip. Extra pins are for EMG Accessories.
- Put the battery in insulating foam and place it securely in the control cavity.
- We suggest that you plug in the instrument and test it before closing the control cavity.



2 Pickups / Toggle Select Switch / 2 Volumes and 2 Tones)

Refer to Diagram #8

- Install the Pickups and route the cables to the control cavity.
 If the cables are too long, wind up the excess and keep it under the pickup.
- 2) Mount the Volume and Tone controls into the body Plug both Neck and Bridge pickup cables onto the Volume Controls as shown. Plug a connect cable from the Bridge (BR) Volume control to the Pickup Buss (Position 1).

Plug a connect cable from the Neck (NK) Volume control to the Pickup Buss (Position 2).

- 3) Plug a connect cable from the Bridge (BR) Volume control to the Bridge (BR) Tone control as shown.
- Plug a connect cable from the Neck (NK) Volume control to the Neck (NK) Tone control as shown.
- 5) Strip the insulation from the switch wires and Insert them into the GREEN Terminal Block and tighten the screws with a small screwdriver. The Bridge pickup goes to the BR Terminal The Neck Pickup goes to the NK Terminal

The Output of the switch goes to the O Terminal

If there is a ground wire coming from the switch, insert it into one of the black terminals on the terminal block.

 6) Plug the output cable onto the Pickup Buss (Position 3) and push the connectors onto the jack as shown.
 WHITE wire onto the TIP (T) contact,

BLACK wire onto the SLEEVE (S) contact

BLACK Battery Negative wire onto the RING (R) contact.

 Plug the RED Wires of the pickups onto the V+ Supply Buss (RED Shroud) along with the RED of the battery clip. Extra pins are for EMG Accessories.

- Put the battery in insulating foam and place it securely in the control cavity.
 - We suggest that you plug in the instrument and test it before closing the control cavity.

